

EnVivo

User manual BT Shower Speaker



Content

Welcome	3
Warnings	4
Important safety instructions	4
Specifications	5
Pack content.....	6
Product diagram	6
Key functions.....	7
Operating the speaker	8
Speaker charging.....	10
Shower & suction functions.....	11
Compatibility.....	11
Trouble shooting guide	12
Disposal.....	15
Warranty card	16

Welcome

You have made an excellent choice with the purchase of this quality EnVivo brand product.

By doing so you now have the assurance and peace of mind, which comes from purchasing a product that has been manufactured to the highest standards of performance and safety, supported by the high quality standards of Accession ApS.

We want you to be completely satisfied with your purchase so this EnVivo product is backed by a comprehensive manufacturer's 3-year warranty and an outstanding after sales service through our dedicated Helpline.

We hope you will enjoy using your purchase for many years to come.

If you require technical support or in the unlikely event that the purchase you have made is faulty, please telephone our Helpline for immediate assistance. Faulty product claims made within the 3 year warranty period will be repaired or replaced free of charge provided that you have satisfactory proof of purchase (keep your till receipt safe!) This does not affect your statutory rights. However, be aware that the warranty will become null and void if the product is found to have been deliberately damaged, misused or disassembled.

Warnings

- This appliance is for household, indoor use only.
- Please do not use or store the unit in high temperature or hazardous location.
- Please do not submerge the unit into water, as this will ruin the speaker.
- The unit comes with a rechargeable battery, so please do not throw or put it in a fire to avoid explosion.
- The warranty for this product is invalidated if the product has been tampered, repaired or modified with in any way.
- Do not listen to music in high volume for long time as it may cause damage to your ears.

Important safety instructions

1. Read these Instructions.
2. Keep these Instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use the product for any purpose other than its intended use.

Specifications


- Model no: ENV-1359
- Bluetooth V3.0
- Transmission distance up to 10M (this may vary according to environment and connected Bluetooth device)
- Output power: 3W
- Frequency: 100Hz - 20KHz
- Sensitivity: -85dbm
- Signal to noise ratio: ≥ 86 dB
- Built-in rechargeable 400mAh Lithium battery
- Playing time up to 3 hours
- Talk time up to 8 hours
- Charging time up to 3 hours
- Standby time up to 24 hours
- Built-in microphone
- Call pick up/hang up function
- IPX4 waterproof level
- USB charge voltage: DV 5V











Pack content

- EnVivo Bluetooth Shower Speaker
- USB charging cable
- User manual

Product diagram



Key functions

1.  Long press power button to turn the unit `ON` or `OFF`
2.  Short press to play or pause music
3.  Volume increase/next track
4.  Volume decrease/previous track
5. DC:5V Use the provided USB cable for charging the unit with DC 5V charger or Connect to Computer
6. MIC Microphone
7. LED indicator Blue light indicates working, Red light indicates charging
8.  Pick up/End call
9. Reset Hard press to restart the unit if the unit appears not to be working.
Please note that it is in between the ,  and  buttons you need to click.

Operating the speaker

A. Power On Status

Long press the power button for several seconds and you will hear the `Beep` sound and the blue indicator light starts blinking quickly.

B. Power Off

Long press the power button for several seconds, and you will hear a `Beep` sound 4 times and the unit will power off.

C. Bluetooth Pairing

If the speaker never has been paired with a Bluetooth device before, you need to follow the instructions below to pair the speaker with your Bluetooth device.

- 1) After hearing the `Beep` sound, the speaker is ready to pair with your Bluetooth device and the Blue LED indicator light will flash quickly.
- 2) Activate Bluetooth on your compatible device and set it to search for compatible devices.
- 3) Select the speaker “ENV-1359” from the list of found devices.

Note:

If the speaker is already connected to another Bluetooth device, the speaker will not appear in the search list, so you need to disconnect the already paired Bluetooth device from the speaker and search again.

- 4) If your device asks for a passkey, enter the digits “0000” and press “OK” (varies depending on the Bluetooth device manufacturers, model and software version).
- 5) If the pairing is successful, the speaker will play a short `Beep` sound and the Blue LED indicator light will be constantly illuminated instead of flashing rapidly and your speaker is ready to play music and receive calls from mobile device. When you play music, the Blue LED indicator light will flash slowly. Once you pause music, the light will flash slowly for a couple of seconds, and then the light is constantly illuminated.



Note:



If the speaker has been paired to the Bluetooth device before you need to follow the pairing instructions below to connect the speaker to the Bluetooth device:

Activate Bluetooth on your compatible device and the speaker will connect automatically to the compatible device and you will hear the `Beep` sound.


A. Playing Music in Bluetooth Mode


After Bluetooth is connected successfully, the speaker will play the music played on your mobile device. Short press the `⏸` button to pause the music, and short press the `⏪` button again to resume the music.

Press shortly the  button to play next track and press shortly the  button to play the previous track.

Hold down the  button to increase the volume and hold down the  button to decrease the volume.

B. Using the Speaker as Hands-free Bluetooth Speaker Phone

When your Bluetooth device is paired with the speaker and if there is an incoming or outgoing call, the speaker will shift from music mode to call mode automatically. In case of an incoming call, press  on the speaker to pick up the call.

After completing the call, press  again to hang up. The music will automatically resume after the call is has ended.

Speaker charging

The speaker has a built-in rechargeable battery. Connect the provided USB cable to a computer or into a DC 5V power adaptor to charge. When the speaker is charging the LED indicator light will be red. When the speaker is fully charged, the red LED will turn off (the charging time is approximately 3 hours). Unplug the Speaker from the power device once the speaker is fully charged.

The battery playing time depends on the playing volume (the higher volume, the shorter playing time). If you have not used the speaker for a long time, please charge it before use. We also recommend that you charge the battery once a month, which can protect the battery and extend the battery life.

Shower & suction functions

This unit is IPX4 certified, which means you can enjoy music & phone calls during the shower. The speakers suction cup can stick to any smooth surfaces.

Note: Please do NOT submerge the unit into water, as this will ruin the speaker.

Compatibility

Wireless : With BLUETOOTH V3.0, including A2DP /HFP/AVRCP.



Trouble shooting guide

Should you experience any trouble while using the speaker, please refer to the following chart.

Fault	Reason	Solution
Not Charging	The USB power adaptor (not included) is not plugged into a wall outlet or the USB cable (included) is not plugged into the 2.0MM jacket on the side of the speaker.	Plug the USB power adaptor (not included) into a wall outlet and plug the USB cable (included) into the 2.0MM jacket of the speaker.
	Wall outlet is not functioning.	Plug another device into the same outlet to confirm the outlet is working.
	Computer USB port is not function.	Make sure your computer power is turned on and try another USB port.

Fault	Reason	Solution
No Sound	The speaker battery is dead.	Recharge the speaker
	The speaker is not connected to the cell phone.	Go through “Speaker Operations” process to connect the speaker.
	Volume set is too low.	Increase the volume of your device.
Speaker cannot be connected	Pairing does not work	Check whether the audio source supports the A2DP protocol
	Audio source is switched off	Switch on the audio source
	Bluetooth is switched off at the audio source.	Switch on the Bluetooth function in the audio source.
	Bluetooth version is not supported.	Use a different playback unit.

Fault	Reason	Solution
Poor Sound quality from a Bluetooth device	Bluetooth device is almost out of range of the speaker	Move your Bluetooth device closer to the speaker

Disposal



Batteries, electrical and electronic equipment (EEE) contain materials, parts and substances, which can be dangerous to the environment and harmful to human health if waste of electrical and electronic equipment (WEEE) are not disposed of correctly.

Batteries, electrical and electronic equipment, which are marked with the WEEE logo (as shown on the left), should not be thrown away with your household waste. Contact your Local Authority Waste Disposal Department, as they will be able to provide details of the recycling options available in your area.



Battery safety:

Do not burn. Risk of explosion.

Do not recharge non-recharge-able batteries.

If swallowed seek immediately medical advice.

Ensure correct polarity.

If not used for extended period remove battery.



The packaging material is partly recyclable. Dispose of the packaging in an environmentally friendly way by bringing it to a public collection centre.



EnVivo

BLUETOOTH SHOWER SPEAKER

Your details:

Name _____

Address _____

 _____ E mail _____

Date of purchase* _____

* We recommend you keep the receipt with this warranty card

Location of purchase _____

Description of malfunction:

Return your completed warranty card to:

Telemarcom Service Center UK

1, Langlands Court

Kelvin South Business Park

East Kilbride,

G75 0YB

United Kingdom

E-mail: accessionx-uk@teknihall.com

AFTER SALES SUPPORT

 0333 200 5846  www.accessionx.com
 1890 917 060

MODEL: 64888

Phone lines available Monday to Friday, 8am - 6pm.
Calls cost 5p per minute from a landline, calls from
mobiles may vary.

3

YEAR WARRANTY